

## DISSASSEMBLING / ASSEMBLING

### Removing the Bolt:

Take out the bolt by turning the bolt handle 60° upwards. Pull it to the rear while pressing the bolt catch on the upper left side of the receiver (see arrow). The bolt can now be easily removed from the action. DO NOT USE ANY FORCE AND ALWAYS ENSURE YOUR RIFLE IS UNLOADED

### Installing the Bolt:

Make sure the safety lever is aligned with the bolt grip. Press the trigger and slide in the bolt forward until it is fully closed, then close the bolt grip by moving it 60° downwards. The rifle is now closed and cocked. DO NOT USE ANY FORCE AND ALWAYS ENSURE YOUR RIFLE IS UNLOADED

## LOADING THE RIFLE

### Magazine:

Press magazine release button underneath the magazine well while pulling the magazine out in order to remove the magazine. Always load your rifle from the magazine. Loading your rifle by hand is only possible with the magazine removed from your rifle. All STANAG AR15 magazines can be used in your rifle. Watch your local laws regarding maximum magazine capacity!

### Loading:

To load your magazine, lay a cartridge on top of the magazine between the magazine lips and press it straight downwards until the cartridge snaps in with a click. Insert the magazine in the magazine well and push it in until the magazine catch locks the magazine in place.

### Bolt Catch:

Depending on the AR-15 STANAG magazine you are using, the magazine follower might work as a last round bolt hold open, meaning that you are not able to close the bolt on an empty magazine. Remove magazine to close the bolt.

### Cocking the Rifle:

After inserting a Magazine with at least one round, open the bolt, slide it backwards and close the bolt again. The bolt is now closed, the firing pin is cocked and a round is loaded into the chamber. While closing the force of the firing spring has to be overcome.

## SAFETY OPERATING YOUR RIFLE

### Loading the Rifle with Safety on:

The rifle can be loaded in a safe manner as follows: Place a cartridge in the magazine and open the bolt. Push the bolt handle forward until the safety lever can be engaged see picture above. Engage the safety by pushing down the safety lever, until the lever is in the down most position. Now fully close the bolt by pushing the bolt grip forward and lowering it. The rifle is now loaded and in a safe condition.

### Safety Lever Engaging:

The rifle is fitted with a firing pin safety, placed on the rear end of the bolt. Press the safety lever downwards to engage the safety. When the safety is engaged, a white dot is visible.

### Safety Lever Disengaging:

Lift the safety lever in the upper position in order to disengage the safety. When the safety is disengaged, a red dot is visible. **Never Disengage your Safety Lever without aiming in a safe direction.**



## HAFTUNGSAUSSCHLUSS

HERA GmbH haftet in keiner Weise für eine unsachgemäße, fahrlässige oder missbräuchliche Handhabung:

Ebenso haftet HERA GmbH in keiner Weise für ein Versagen der Waffe, für Körperverletzungen oder Sachschäden, die ganz oder teilweise entstehen durch:

- jegliche Änderungen an der Waffe
- ungeeigneter Munition jeglicher Art
- mangelhafte Pflege bzw. Reinigung
- missbräuchliche oder unsachgemäße Verwendung

Ebenso haftet HERA GmbH unter keinen Umständen für Zufalls- oder Folgeschäden wie z.B. Sachschäden, Geschäfts-, Einkommens- oder Gewinnverlust.

## EXCLUSION OF LIABILITY

HERA GmbH does not provide any liability or warranty for improper or careless use of this firearm.

HERA GmbH also does not provide any liability or warranty for physical or property damages entirely or partly resulting of:

- modifications of the firearm
- improper ammunition of any kind
- bad care or cleaning
- improper or incorrect use

HERA GmbH does not, under any circumstances, accept liability for accidental or consequential damages like property damages, business loss, and loss of income or profit.

## ALLGEMEINE WARNHINWEISE

1. Schießen Sie nie unter dem Einfluss von Alkohol, Drogen oder Medikamenten.
2. Zielen Sie mit Ihrer Waffe nie auf etwas, worauf Sie nicht zu schießen beabsichtigen.
3. Übernehmen Sie die Waffe stets in der Annahme das diese geladen ist.
4. Bevor Sie die Waffe ablegen oder übergeben, überzeugen Sie sich immer davon, dass sie nicht geladen ist.
5. Bewahren Sie die Waffe ausnahmslos ungeladen sowie getrennt von der Munition auf.
6. Verwenden Sie die Waffe nie zu anderen Zwecken als zum Schießen.
7. Lassen Sie eine gespannte und geladene Waffe niemals ohne Aufsicht.
8. Überzeugen Sie sich vor dem Laden der Waffe, das die Laufbohrung, Kammer und Verschluss sauber und frei von Fremdkörpern sind. Falls die Waffe durch das Schießen verschmutzt ist, ist diese vor der Nutzung zu reinigen.
9. Nicht mit der Waffe schießen, wenn Sie sich nicht sicher sind, welche Munition Sie benutzen. Keine nicht gekennzeichnete oder wieder geladene Munition unbekannter Herkunft, Munition mit geplatzter, deformierter oder eingebroter Hülse oder beschädigte Munition benutzen. Das Wiederaufladen ist eine spezialisierte Tätigkeit und falsch geladene Munition kann extrem gefährlich sein. Das Resultat können schwere Beschädigung oder die Zerstörung der Waffe und ernste Verletzungen oder Tod des Schützen oder auch weiterer Personen sein. Benutzen Sie nur saubere, trockene, fabrikmäßig hergestellte Originalmunition von hoher Qualität, in einem guten Zustand, die dem Kaliber Ihrer Waffe entspricht.
10. Gehen Sie stets mit Ihrer Waffe so um, als ob sie geladen wäre.
11. Tragen Sie beim Schießen stets Schutzausrüstung wie Gehörschutz und Schutzbrille.
12. Wenn die Waffe geladen und gespannt ist, lassen Sie die Sicherung in der Stellung gesichert bis Sie schussbereit sind. Zielen Sie beim Entsichern stets in eine sichere Richtung.
13. Blockieren Sie niemals die Hülsenauswurfförmung.
14. Betätigen Sie nicht den Abzug, wenn Sie nicht auf ein Ziel zielen oder/und zum Schießen nicht bereit sind.
15. Bevor Sie den Abzug betätigen, kontrollieren Sie Ihre Schussrichtung wie den Raum dahinter.
16. Schießen Sie nie auf eine Wasseroberfläche oder auf harte Oberflächen.
17. Schießen Sie nicht, wenn sich in der Nähe ein Tier befindet, das nicht bzgl. Schussgeräuschen desensibilisiert wurde.
18. Wenn Sie die Waffe in den Händen halten gehen Sie stets verantwortungsvoll mit dieser um.
19. Im Fall eines Zünd- oder Schussversagens halten Sie die Waffe weiter auf das Ziel oder in eine sichere Richtung und warten Sie 30 Sekunden ab.
20. Überzeugen Sie sich immer vor Reinigen, Lagern, oder Transportieren, dass Ihre Waffe nicht geladen ist.
21. Bewahren Sie Waffe und Munition in einem abgetrennten und verschlossenen Raum auf.
22. Ändern Sie nie an den Waffenbestandteilen ohne hinreichende Ausbildung bzw. Beratung durch eine Fachkundige Person.

## GENERAL WARNINGS

1. Never use a firearm under the influence of alcohol or drugs.
2. Never point the firearm at anything you are not intended to shoot at.
3. Always receive and treat the firearm as it where loaded from others.
4. Always make sure that the firearm is not loaded before laying it down, handing it over to another person or storing.
5. Always store the firearm unloaded with the striking mechanism released.
6. Never abuse the firearm by using it for any purposes other than shooting.
7. Never leave your firearm unattended.
8. Always ensure that the barrel, chamber and action are clean and clear of obstructions. If the firearm becomes dirty during usage, it must be cleaned immediately. Always clean the firearm after use.
9. Do not shoot the firearm, unless you are certain about the ammunition you are using. Do never use unmarked or hand-loaded ammunition from unknown sources, ammunition with a cracked, deformed or dented case or/and with a damaged bullet or damaged in any other way. Reloading is an expert activity and incorrectly reloaded ammunition may be extremely dangerous. It may result in heavy damage or destruction of the firearm and serious injury or death of the shooter or other persons. Always use clean and dry original high quality commercially manufactured ammunition, which corresponds to the caliber of the firearm and is legal to use and/or shoot in your jurisdiction.
10. Treat or handle your firearm always as loaded.
11. Always wear personal protection as safety glasses and ear protection while shooting.
12. When the firearm is loaded and a round is in the chamber, always keep the safety applied until you are ready to fire. Keep the firearm pointed in a safe direction when disengaging the safety.
13. Never block the ejection port.
14. Never pull the trigger or put your finger within the trigger guard unless you are aiming at a target and ready to fire.
15. Always make absolutely sure of your target and the area behind it before pulling the trigger.
16. Never shoot at water or hard surfaces.
17. Never fire near or close to an animal unless it is desensitized against the noise and / or muzzle blast or fire.
18. Always handle the firearm responsible.
19. In case it fails to fire, hold the firearm pointed in a safe direction and wait at least 30 seconds. If a slow ignition has occurred, the cartridge will usually fire within 30 seconds.
20. Always make sure your firearm is not loaded before cleaning, storing or travelling and be sure to remove any unused ammunition.
21. Always keep and store your firearm and ammunition in separate secure locations.
22. Never alter or change any parts of your firearm without proper knowledge, qualification or prior advice from a specialist / gunsmith.

## ACHTUNG

Überzeugen Sie sich vor jeder Nutzung das Laufbohrung, Kammer und Verschluss sauber sowie frei von Fremdkörpern sind. Falls Ihre Waffe durch das Schießen verschmutzt ist, ist diese vor der nächsten Nutzung zu reinigen. Fremdkörper sind vor der Nutzung zu entfernen.

Achten Sie vor der ersten Inbetriebnahme auf im Lauf befindliches Konservierungsmittel. Dieses ist vor der ersten Nutzung zu entfernen.

## ATTENTION

Always ensure that barrel, chamber and action are clean and clear of obstructions. If the firearm becomes dirty during usage, it must be cleaned immediately. Always clean the firearm after use. Any foreign material has to be removed before use.

Prior to the first use of your firearm take attention to any preservative left in the barrel. Any preservative left has to be removed before first use.

